




Weighing method	Description
<p><b><u>Sequential</u></b> 2 Axle, 2 Plate</p> <p>Accuracy: <math>\pm 1\sim 3\%</math> (WIM: <math>\pm 3\%</math>)</p> <p><b>[Scale ID]</b> Axle 1<sub>LF</sub> Left: 1 / Right: 2</p>	 <p><b>⚠</b> In case of Weigh-In-Motion (WIM), you must install the dummy pad (longer to the length of the vehicle) back and forth on scale.</p>
<p><b><u>Synchronous</u></b> 2 Axle, 4 Plate</p> <p>Accuracy: <math>\pm 0.1\%</math></p> <p><b>[Scale ID]</b> Axle 1<sub>LF</sub> Left: 1 / Right: 2 Axle 2<sub>LF</sub> Left: 3 / Right: 4</p>	
<p><b><u>Synchronous</u></b> 3 Axle, 6 Plate</p> <p>Accuracy: <math>\pm 0.1\%</math></p> <p><b>[Scale ID]</b> Axle 1<sub>LF</sub> Left: 1 / Right: 2 Axle 2<sub>LF</sub> Left: 3 / Right: 4 Axle 3<sub>LF</sub> Left: 5 / Right: 6</p>	 <p><b>i</b> Can be installed up to maximum 6 axles</p>