


CL8000 QUICK GUIDE (PCA TYPE)

This GUIDE is an installation guide for CL8000-PCA.
Disassembly procedures are performed in reverse order of assembly.

Assembly Procedure

1. When the packaging material is removed, it is organized as shown below.



2. Remove the cover from the Main Display and connect it as shown below.



Route the cables on the Rear Display through the holes of the Pole Cover.



Arrange the cables as shown.

3. Connect the AC cable. First, turn on the Main Switch on the bottom of the scale. And press the Operating Switch on the bottom of the display to turn the scale on.